

# TUBCO WHIRLPOOLS LTD.

## MAINTENANCE GUIDE

### **SURFACE**

Use a liquid detergent with a soft sponge or cloth, and warm water. Do not use abrasive powders, metal soap pads, acetone, dry cleaning fluid, window cleaning sprays, or ammonia compounds.

For tar or paint, you may use turpentine. Do not use paint thinners, benzene, or mineral spirits.

Stains, light scratches, and dull areas can be removed by rubbing with an automotive cleaning compound. Follow with an application of any household paste wax. Vinegar can be used for persistent stains.

### **PUMP**

No periodic maintenance is required. The motor bearings are lubricated for life, and the mechanical shaft seal is water lubricated and self-adjusting.

### **PIPING**

Piping should be cleaned periodically by running the Whirlpool for 10-15 minutes using 2-3 tablespoons of automatic dishwasher detergent. Drain the tub and follow with a rinse by refilling with plain water and running the Whirlpool for 10 minutes.



### **RESULTS MAY VARY DUE TO:**

- Temperature of water
- Measurement of cleaning products
- Changes in cleaning formulas
- Condition of fixture